

PAN WASHER DAILY STARTUP AND CLOSING INSTRUCTION

Wash Operation



1. Close drain valve.
Left side of pan washer.



2. Place pump inlet screen in position-left rear corner of wash tank.



3. Position scrap trays in proper place.



4. Turn power switch to 'on' and close door.



5. Push Fill button to fill wash tank.



6. Amber light will illuminate when water level is reached.



7. Wait until wash temperature reaches 155-160 F (68-71 C).



8. Make sure rinse tank temperature reaches 200 F (96 C).



9. Load pans into rack; make sure papers and large food items are removed before loading pans!



10. Turn wash selector to desired setting.
(Light/5 min.
Medium/7 min.
Heavy/9 min.)



11. Press "start" button. Washlight should illuminate red.



12. When wash light goes off, cycle is complete.

SPECIAL NOTE: DOOR MUST BE SHUT AT ALL TIMES TO OPERATE MACHINE AND PREVENT HEAT LOSS!

Shift Maintenance (minimum of every 8 hours)



1. Turn power switch "OFF"



2. Open drain valve and drain machine completely.



3. Scrap trays must be removed and cleaned thoroughly.



4. Brush residue from immersion heaters daily. Electric models only.




5. Carefully clean residue from level sensor daily.

6. Clean wash tank and inside of machine entirely with spray gun and hose.



7. Wash and rinse nozzles must be inspected for blockage and cleaned.



8. Pump inlet screen must be removed and cleaned thoroughly.



9. Replace pump inlet screen and clean inside of machine entirely with hose and brush.

DO NOT ALLOW ANY FOREIGN MATERIAL TO ENTER PUMP INLET!!
NOTE: Final inspection should be carried out for any build-up residue. Entire machine must be clean before installation of scrap trays and filling with water.



LVO Manufacturing
808 N 2 Ave East
Rock Rapids, IA 51246
(712) 472-3734 • (800) 346-5749