



☐ Terminal Block (BTB – Bottom row of Terminal Blocks, TTB – Top row of Terminal Blocks)
 □ Component Terminal
 — Wired Connection
 - - - Component Internal Connection
 - - - Wired Connection (Optional)

Transformer
(Transformer tap layout/voltages may vary)

115VAC
To Transformer

0VAC